Antifouling paint application guide

Step by step application:

Seajet 117 Multipurpose Epoxy Primer - 2 coats Seajet 034 Emperor A antifouling paint - 2 coats

Surface preparation:

- · Remove release agent residues with acetone
- · Mask the edge of the waterline with good quality masking tape
- · Matt the bottom surface with sandpaper grit P80 P100
- · Dust and degrease the surface again with SeaJet Thinner E (use nitrile / latex gloves), wash immediately before painting, avoid leaving hand marks on the fuselage

Tips:

You can see if dust is present by wiping the surface with a clean white cloth

Preparation of the paint:

The coating should be applied immediately after surface preparation. By following this principle, it is ensured that the surface is not re-contaminated.

- \cdot The paints should be at the same temperature as the surroundings and the hull,
- · Foundation carefully mix the base in a can, then combine the ingredients in the right proportions and mix thoroughly,
- · Antifouling paint mix thoroughly in the can, then mix the white and black paint in the proportions 2: 1

Tips:


We recommend that you note the "batch number" of the paint applied to a specific boat in case of any complaints.


Application site

The paints should be applied in a place free of dust and dust, well ventilated, at a temperature of about 18-20 degrees C. During application, precautions should be taken in accordance with the MSDS

Tools and method of application:

- · Apply paints with a roller, e.g. velor fleece 4-6 mm
- \cdot Cover the roller with tape before painting and then remove it to remove loose hair and increase the fur volume
- · Use paint trays when applying paint
- · Apply Seajet 117 Epoxy Primer in layers with a thickness of approx. 170 microns wet (use measuring comb) in two coats. Another layer after the "thumb test" after about 1 hour. The primer should evenly and completely cover the gelcoat. There should be no gel coat gaps through the primer. Theoretical spreading rate is 10 m2 with a wet film thickness of 85 microns.
- · Apply the Seajet 034 Emperor A antifouling paint after 1-2 hours. (thumb test) and after a maximum of 24 hours after applying the epoxy primer to a total thickness of 180 microns wet (use a measuring comb) in two coats. Another layer after about 1 hour. The paint should evenly and completely cover the undercoat. There should be no clearances of the gray primer through the paint. Theoretical coverage of 12m2 with a wet film thickness of 90 microns.





	ART O.	ITEM	DESCRIPTION	SUPPLIER	MODEL	SIZE, CAPACITY	MATERIAL
	1	AXO000040,A	EPOXY PRIMER	SEAJET	117 MULTIPURPOSE EPOXY PRIMER	3 x 2,5 LITERS	EPOXY
:	2	AXO0000297	ANTIFOULING	SEAJET	SEAJET 034 EMPEROR A, WHITE	7 X 1 LITER	EPOXY

This document and the information contained in it is proprietary and confidential information of Axopar Boats Oy. Neither this document nor any of the information contained herein may be reproduced, disclosed to others, or used for any purpose other than for the purpose it has been provided without the marks of the purpose of the purp

prior writteri periri	ission of Axopai Bi	dats Oy.			ITEM	F	REV
A	X	JF			AXO900102	9	Α
BOAT MODEL	_			MODEL YEAR	DRAWING	F	REV
AX45				2022	DRW00952		0
	BY	DATE	DESCRIPTION	•	•	SCALE	PAGE

1:45 1 / 2



CREATED		10.11.2022	ANTIFOULING, WHITE
CHECKED	L.C.	10.11.2022	TECHNICAL DESCRIPTION
CCEPTED	MPE	14.11.2022	Manufacturing Specification

